




3D POCKETBEAM PRO



Thank you for purchasing this Merlin Product. Please read the instruction manual carefully before using the product.

The documentation provided will allow you to fully enjoy all the features this unit has to offer.

Please save this manual for future reference.

Instructions

The Pocketbeam Pro is a portable android projector with various input methods. It has a built in battery which means you can take it with you and is perfect for presentations at work or movies at home. One of the most unique features of this product is the touch control pad.

Charging:



Before first use please connect the projector to the supplied power adapter and fully charge it before using.

Power On/Off:

- Press and hold the power button on the projector for about 3 seconds to power it up.
- To power off the projector press the power button twice or use the supplied remote control.

Focus adjustment:

Once the projector is powered up the focus can be set using the focus buttons on the side of the projector. The projector is now ready to be used.



Connecting to Wi-Fi:

- Once the unit is switched on use the remote control to select the "Wi-Fi" icon on the "Home" Screen.
- Slide the switch the Wi-Fi switch to on.
- Select your SSID from the list and enter your password.
- A wireless icon will appear in the status bar once connected.

Connecting a Bluetooth device:

This projector has a Bluetooth function that allows you to connect some products to it wirelessly. For example a Bluetooth speaker.

- First select the Bluetooth icon from the "Home" Screen.
- Slide the Bluetooth option to "On".
- The projector will scan for Bluetooth devices. Pair with your device and enter the password if needed.
- Once connected a BT icon will appear in the status bar.





Home Screen:

From the home screen various applications and functions can be selected.

- To change any setting select the "Setting" icon from the home screen and choose your function.
- Shortcuts to your favorite apps can be added to the home screen.
- Any of the inputs can be selected from the home screen.



Remote control and input method:



1. Menu 3. Return 5. Scroll vertical
2. Home 4. Touch panel 6. Scroll horizontal

- There are two methods by which the projector can be controlled. One is using the remote control and the other is via the touchpad at the top of the unit.
- Additionally the Merlin Airkey can also be used to control the unit. The Airkey has a full qwerty keyboard to easily type information.

3D Mode:

To set and adjust the 3D settings of the projector please press the 3D button on the remote control.

Ushare and Mirroring:

The projector supports sharing and mirroring on Android and iOS.

- Before starting Ushare make sure the projector and all devices are on the same Wi-Fi network.
- On the projector go to "Apps" and select Ushare.
- Scan the QR code on the screen to download the app.
- Once downloaded open the app.
- For Android select the "ushare-1736" to connector to the projector
- For iOS, swipe up and select Airplay function.
- Select the projector from the options available.

FAQ

Q) How is the keystone adjusted in the projector?

A) Under the device settings in the settings menu the keystone can be adjusted manually or set to automatically changed.

Q) The projector is not powering up.

A) Check if the charger is properly connected to the projector and the mains and make sure that the projector have enough charge to operate.

Q) No Display from HDMI.

A) Re-check the connections of the projector from the source. Loose connection or faulty cable(s) can cause this issue. Adjusting the source's resolution may also sort it out.

Q) The display is not clear.

A) Properly adjust its focus and make sure to use appropriate screens. Projection quality are also affected by the screen quality in terms of brightness and color.

Q) No sound is coming from the projector.

A) Audio depends on the volume of both the projector and its source, so make sure that both are adjusted accordingly to get the desired output. Connections can also be the problem, using another cable will help you troubleshoot the issue.

Maintenance

1. Retain these instructions for future use.
2. Clean the product with a damp cloth and mild soap.
3. Do not expose this product to rain or moisture.
4. Be careful not to turn or twist the cables used in this product too much as it can lead to malfunction and failure.
5. This product is not designed to be submerged in water and will malfunction if this occurs.
6. This product has no user serviceable items inside. Do not open this product as the user risk injury and would void the warranty.
7. Keep unit away from strong magnetic fields to avoid interference with the product.



LIMITED WARRANTY

Merlin Products are covered by a limited one-year warranty policy. If the product suffers from a manufacturing defect, the customer will receive a replacement if claimed within 15 days of the purchase date. Otherwise, the product will be inspected for possible repair options. The product will either be repaired and returned free of charge, or replaced. All repair services past the one-year warranty period will be charged for any repairs that need to be made.

If the client is located outside the UAE, or is otherwise unable to personally deliver the defective product to our service center or retail outlets, he/she may send it via post at his/her own cost. The repaired/replaced product will then be returned to the client via courier mail at Merlin's cost, as long as the warranty period is still active.

Important: This limited warranty DOES NOT COVER normal wear and tear, accidents, damage during transit, misuse, abuse or neglect. Attempting to disassemble the unit will render the warranty null and void.

REGISTER
NOW

We hope you enjoy the quality of Merlin Digital product.

Please take out a few minutes to register your product at merlin-digital.com/register to avail:


- Special discounts and promotions on other Merlin products
- Exclusive information on new products and innovations
- Reminders about product firmware downloads, updates and upgrades
- Competitions and exciting giveaways

To learn more about Merlin products visit our site at: www-merlin-digital.com or like our Facebook page on facebook.com/merlin.digital.gadgets

For enquiries and information call our toll free number 800-MERLIN (Sat-Thu, 9 am - 6 pm)

Contact our support staff for troubleshooting and any other enquiries relating to your Merlin product by sending an email at support@merlin-digital.com and your issue will be resolved within 48 hours.

REGISTER
for exclusive
product releases
and future
prize drawings!



For a complete list of our worldwide locations,
visit <http://merlin-digital.com/contacts>