



SKETCHPAD X




Thank you for purchasing this Merlin Product. Please read the instruction manual carefully before using the product.

The documentation provided will allow you to fully enjoy all the features this unit has to offer.

Please save this manual for future reference.

Instructions

The Merlin Sketchpad X is a portable digital chalkboard. It is perfect for adults and children alike and very versatile. Use it to make notes while at work or the shopping list for your groceries. The children can use it to draw picture, play word games and many more. They can also take it on long trips in the car to keep them occupied.




Usage:


- To write on the Merlin Sketchpad, remove the pen provided with the Sketchpad and gently draw on the surface. Note: Only use the pen provided. Other pens may permanently damage the surface and product.
- The thickness of the line can be changed by pressing harder on the pen while writing. Please do not press too hard otherwise it can damage the product.

Once you finished with your notes/drawing you can clean the Sketchpad by pressing the Erase button. This will clear the display and you can start afresh with new notes/drawings.

This product has an erase lock button. This will prevent the picture from being erased when the button is pressed.




Turn off Erase Lock



Turn on Erase Lock

Battery replacement: After a long time of usage it might occur that the sketchpad does not erase when the button is pressed. If this happens it means the battery has run out. Please replace the battery with a CR2032 unit. If you feel uncomfortable to replace the battery please contact the service center for assistance.



FAQ

Q) The Sketchpad does not erase.

A) Please check that the erase lock function is set to unlock and proceed with erasing. If it still does not erase please replace the battery.

Maintenance

1. Retain these instructions for future use.
2. Clean the product with a damp cloth and mild soap.
3. Do not expose this product to rain or moisture.
4. Be careful not to turn or twist the cables used in this product too much as it can lead to malfunction and failure.
5. This product is not designed to be submerged in water and will malfunction if this occurs.
6. This product has no user serviceable items inside. Do not open this product as the user risk injury and would void the warranty.
7. Keep unit away from strong magnetic fields to avoid interference with the product.



LIMITED WARRANTY

Merlin Products are covered by a limited one-year warranty policy. If the product suffers from a manufacturing defect, the customer will receive a replacement if claimed within 15 days of the purchase date. Otherwise, the product will be inspected for possible repair options. The product will either be repaired and returned free of charge, or replaced. All repair services past the one-year warranty period will be charged for any repairs that need to be made.

If the client is located outside the UAE, or is otherwise unable to personally deliver the defective product to our service center or retail outlets, he/she may send it via post at his/her own cost. The repaired/replaced product will then be returned to the client via courier mail at Merlin's cost, as long as the warranty period is still active.

Important: This limited warranty DOES NOT COVER normal wear and tear, accidents, damage during transit, misuse, abuse or neglect. Attempting to disassemble the unit will render the warranty null and void.

REGISTER
NOW

We hope you enjoy the quality of Merlin Digital product.

Please take out a few minutes to register your product at merlin-digital.com/register to avail:


- Special discounts and promotions on other Merlin products
- Exclusive information on new products and innovations
- Reminders about product firmware downloads, updates and upgrades
- Competitions and exciting giveaways

To learn more about Merlin products visit our site at: www-merlin-digital.com or like our Facebook page on facebook.com/merlin.digital.gadgets

For enquiries and information call our toll free number 800-MERLIN (Sat-Thu, 9 am - 6 pm)

Contact our support staff for troubleshooting and any other enquiries relating to your Merlin product by sending an email at support@merlin-digital.com and your issue will be resolved within 48 hours.

REGISTER
for exclusive
product releases
and future
prize drawings!



For a complete list of our worldwide locations,
visit <http://merlin-digital.com/contacts>