



AQUATRAX **MINI**




Thank you for purchasing this Merlin Product. Please read the instruction manual carefully before using the product.

The documentation provided will allow you to fully enjoy all the features this unit has to offer.

Please save this manual for future reference.

Product introduction

Product Structure:



1. Power switch
2. Previous/Vol-
3. Multi-function button (MFB)
4. Next/Vol+
5. Reset
6. Micro USB charging interface
7. Micro SD card slot
8. Charging indicator
9. LED status indicator

Power On/Off

1. To turn on, long press the power switch for 3 seconds, the LED status indicator flashes white.
2. To turn off, long press the power switch for 3 seconds, the LED goes off.

Bluetooth connection

1. Turn on the Bluetooth speaker, the LED indicator flashes white continuously while waiting for pairing; you can long press MFB to disconnect and enter pairing mode.
2. Then activate the Bluetooth of your phone and search for 'Merlin Aquatrax Mini'.

3. Since the speaker can automatically reconnect to the last paired device, when the Bluetooth of your device turns on, it will automatically reconnect.

Answering incoming calls:

1. Short press the MFB to answer incoming calls.

Tip: Since some mobile phones default to answer calls via their own receiver, please refer to the instructions of your phone and set accordingly.

Ending the call:

1. Press the MFB button once to end the current call.

Refuse incoming calls:

1. Press the power switch for 3 seconds to reject when there is an incoming call.

Volume adjustment:

1. Short press the "-" for VOL -;
2. Short press the '+' for VOL +.

Music playing:

1. Short press the ▶ to pause/play;
2. Long press the "..." for Prev;
3. Long press the '+' for Next.

Charging:

1. As product has built-in non-removable and rechargeable battery, please use the provided micro USB cable to charge.
2. Charging voltage and current is 5V/1A. Please ensure to charge the speaker with the input power below 5V/1A.
3. Charge if the LED indicator lights up red, and LED goes off upon charging finished.

Notes:

A. Please choose the charger that is certified by the regular manufacturer.

B. As normal with all rechargeable batteries, the battery performance may decrease due to repeated charging and speaker usage.

Warnings:

1. Please follow the instructions to operate
2. Please charge the product with input power below 5V/1A, in order to protect the battery;
3. Please do not immerse this product in any liquid or splash any liquid on this product.
4. Please store or use the product in a normal temperature environment.
5. Please keep the product away from heat sources such as radiators, hot air regulators, stoves or other heat generating instruments. As it is not anti high temperature.
6. Don't jam the ports of the product, such as charger port, LED port and microphone etc.
7. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the maximum level for a long time.

FAQ:

Q) How long does the Aquatrax Mini play for?
A) 5 Hours

Q) Why is the speaker is not pairing to my phone?
A) Please check that the speaker is charged



LIMITED WARRANTY

Merlin Products are covered by a limited one-year warranty policy. If the product suffers from a manufacturing defect, the customer will receive a replacement if claimed within 15 days of the purchase date. Otherwise, the product will be inspected for possible repair options. The product will either be repaired and returned free of charge, or replaced. All repair services past the one-year warranty period will be charged for any repairs that need to be made.

If the client is located outside the UAE, or is otherwise unable to personally deliver the defective product to our service center or retail outlets, he/she may send it via post at his/her own cost. The repaired/replaced product will then be returned to the client via courier mail at Merlin's cost, as long as the warranty period is still active.

Important: This limited warranty DOES NOT COVER normal wear and tear, accidents, damage during transit, misuse, abuse or neglect. Attempting to disassemble the unit will render the warranty null and void.

REGISTER
NOW

We hope you enjoy the quality of Merlin Digital product.

Please take out a few minutes to register your product at merlin-digital.com/register to avail:


- Special discounts and promotions on other Merlin products
- Exclusive information on new products and innovations
- Reminders about product firmware downloads, updates and upgrades
- Competitions and exciting giveaways

To learn more about Merlin products visit our site at: www-merlin-digital.com or like our Facebook page on facebook.com/merlin.digital.gadgets

For enquiries and information call our toll free number 800-MERLIN (Sat-Thu, 9 am - 6 pm)

Contact our support staff for troubleshooting and any other enquiries relating to your Merlin product by sending an email at support@merlin-digital.com and your issue will be resolved within 48 hours.

REGISTER
for exclusive
product releases
and future
prize drawings!



For a complete list of our worldwide locations,
visit <http://merlin-digital.com/contacts>