



## Sonic X ANC




Thank you for purchasing this Merlin Product. Please read the instruction manual carefully before using the product.

The documentation provided will allow you to fully enjoy all the features this unit has to offer.

Please save this manual for future reference.


### Product Overview



### Automatic On/Off


**Auto on:** Take the earphone out of the charging box, and the earphone will be on automatically.

**Auto off:** Put the earphone into the charging box, the earphone will be disconnected and turned off.



### Bluetooth Pairing

Two ear buds will be paired automatically with each other when you remove from the case and turned on. Pairing between the earplugs and the mobile phone: Take out the earplugs from the charging box, the main earplug (right) will enter into pairing mode automatically (red and green lights on the main earplug flicker alternatively), and enable Bluetooth of the mobile phone to search, pair and connect.




### Active Noise Reduction Function:


- When two ear buds are being used, hold the touch key on the right ear bud for 2 seconds, and Active noise reduction function is activated or canceled.



### Call Functions



### Music Control



### Voice Assistant

When two ear buds are in use, hold the touch key on the left ear bud for 2-3 seconds.

### Clear Bluetooth Pairing

Take the two ear buds out of the charging box, and then put them back into the charging box. When the indicators on the earplugs are in red for charging, hold touch key for 10 seconds simultaneously. When the indicator flickers for 3 times, pairing information will be cleared.

Note: The user cannot clear connecting and pairing information for the left and right earplugs through any key.



**Light Indicator Status:**

Earphone Mode	Status of indicator
ON	Green light is on for 1 second
OFF	Red light is on for 1 second
Standby	No light
Connect again	No light
Earphone pairing state	Red and green lights flicks alternatively
Earphone charging state	Red light is on
Earphone is fully charged	No light
Charging box is fully charged	3 LED lights are on

**FAQ:**

Q) Can't find the headphones in the Bluetooth list?

A) Please make sure your headphones are not connected with any other devices before searching the headphones from Bluetooth settings. If it is connected with other device, either switch off the Bluetooth of the connected device or clear the pairing in the earphones by press and hold the Touch key for 10 seconds. ( Before try to clear pairing make sure headphones are switched off)

Q) Can't turn on the headphones?

A) Make sure both headphones are fully charged.

**Maintenance:**

1. Retain these instructions for future use.
2. Clean the product with a damp cloth and mild soap.
3. Be careful not to turn or twist the cables used in this product too much as it can lead to malfunction and failure.
4. This product is not designed to be submerged in water and will malfunction if this occurs.
5. This product has no user serviceable items inside. Do not open this product as the user risk injury and would void the warranty.
6. Keep unit away from strong magnetic fields to avoid interference with the product.



### LIMITED WARRANTY

Merlin Products are covered by a limited one-year warranty policy. If the product suffers from a manufacturing defect, the customer will receive a replacement if claimed within 15 days of the purchase date. Otherwise, the product will be inspected for possible repair options. The product will either be repaired and returned free of charge, or replaced. All repair services past the one-year warranty period will be charged for any repairs that need to be made.

If the client is located outside the UAE, or is otherwise unable to personally deliver the defective product to our service center or retail outlets, he/she may send it via post at his/her own cost. The repaired/replaced product will then be returned to the client via courier mail at Merlin's cost, as long as the warranty period is still active.

Important: This limited warranty DOES NOT COVER normal wear and tear, accidents, damage during transit, misuse, abuse or neglect. Attempting to disassemble the unit will render the warranty null and void.

REGISTER  
NOW

We hope you enjoy the quality of Merlin Digital product.

Please take out a few minutes to register your product at [merlin-digital.com/register](http://merlin-digital.com/register) to avail:


- Special discounts and promotions on other Merlin products
- Exclusive information on new products and innovations
- Reminders about product firmware downloads, updates and upgrades
- Competitions and exciting giveaways

To learn more about Merlin products visit our site at: [www-merlin-digital.com](http://www-merlin-digital.com) or like our Facebook page on [facebook.com/merlin.digital.gadgets](https://facebook.com/merlin.digital.gadgets)

For enquiries and information call our toll free number 800-MERLIN (Sat-Thu, 9 am - 6 pm)

Contact our support staff for troubleshooting and any other enquiries relating to your Merlin product by sending an email at [support@merlin-digital.com](mailto:support@merlin-digital.com) and your issue will be resolved within 48 hours.

REGISTER  
for exclusive  
product releases  
and future  
prize drawings!



For a complete list of our worldwide locations,  
visit <http://merlin-digital.com/contacts>