



Wi-Fi Digital Photo Frame

Digitalize your memories!




Thank you for purchasing this Merlin Product. Please read the instruction manual carefully before using the product.

The documentation provided will allow you to fully enjoy all the features this unit has to offer.

Please save this manual for future reference.

Instructions

- 1) To power the glasses on, press the power button (located on the left temple) once. A green LED in the power button should light up, indicating that the device is on.
- 2) To power the glasses off, press the power button once. The green LED should flicker thrice, indicating that the device has been turned off.
- 3) To check the battery level, press the power button once. If the LED turns red, the device needs charging.



Maintenance

- 1) Ensure that the distance between the glasses and 3D projector is less than 10 meters.
- 2) Do not apply excessive force when inserting the charging cable.

- 3) Do not expose the glasses to extreme temperatures.
- 4) Keep the glasses in a dry place, away from sunlight.
- 5) Use only lint-free cloth (included) to clean the glasses.
- 6) Do not pour water or other liquids on the glasses.
- 7) Stop using the glasses if your eyes get strained.

FAQ

- Q) The device is not powering up.
A) Check battery level by pressing the power button once.
- Q) I can notice screen flickering.
A) Avoid watching 3D images under fluorescent light or 3-wavelength lamps.
- Q) The device is not working properly.
A) The device may not work properly if there are other 3D products or electronic devices in use near the glasses or the 3D projector.
- Q) The device shuts off automatically.
A) The device will automatically turn off after 60 seconds if the channel is changed or if the 3D projector is turned off.

LIMITED WARRANTY

Merlin Products are covered by a limited one-year warranty policy. If the product suffers from a manufacturing defect, the customer will receive a replacement if claimed within 15 days of the purchase date. Otherwise, the product will be inspected for possible repair options. The product will either be repaired and returned free of charge, or replaced. All repair services past the one-year warranty period will be charged for any repairs that need to be made.

If the client is located outside the UAE, or is otherwise unable to personally deliver the defective product to our service center or retail outlets, he/she may send it via post at his/her own cost. The repaired/replaced product will then be returned to the client via courier mail at Merlin's cost, as long as the warranty period is still active.

Important: This limited warranty DOES NOT COVER normal wear and tear, accidents, damage during transit, misuse, abuse or neglect. Attempting to disassemble the unit will render the warranty null and void.

REGISTER NOW


We hope you enjoy the quality of Merlin Digital product. Please take out a few minutes to register your product at merlin-digital.com/register to avail:

- Special discounts and promotions on other Merlin products
- Exclusive information on new products and innovations
- Reminders about product firmware downloads, updates and upgrades
- Competitions and exciting giveaways

To learn more about Merlin products visit our site at: www-merlin-digital.com or like our Facebook page on facebook.com/merlin.digital.gadgets
For enquiries and information call our toll free number **800-MERLIN** (Sat-Thu, 9 am - 6 pm)

Contact our support staff for troubleshooting and any other enquiries relating to your Merlin product by sending an email at support@merlin-digital.com and your issue will be resolved within 48 hours.

REGISTER
for exclusive product releases and future prize drawings!



For a complete list of our worldwide locations, visit <http://merlin-digital.com/contacts>