



ACTIFIT TRACK



Thank you for purchasing this Merlin Product. Please read the instruction manual carefully before using the product. The documentation provided will allow you to fully enjoy all the features this unit has to offer.

Please save this manual for future reference.

Instructions

Charging:

1. Before using ActiFit Track, charge the device using the included charging cradle.
2. Connect a standard micro USB cable and 5V/1A charger to the charging port of the cradle, and then place the watch on the cradle in a way that the contact pins on the charging cradle align with the contact points under the watch. The charging time is about 2 hours.
3. Press and hold the 'Home' button to turn the watch on.

Controls:

1. The watch can be controlled using the Home and Mode buttons as well as the Menu Dial in the middle.
2. By default, the watch screen turns off after 15 seconds. Press the Home or Mode buttons to activate the watch screen.
3. Press the Home button to see the dial face; this is the Home Screen. Touch and hold anywhere on the Home Screen to choose a different dial face.
4. Press the Mode button while at the Home Screen to bring up the Activity Tracking option. Rotate the Dial to go through the options and gently press the Dial in to select your desired activity.
5. While at the Home Screen, swipe down to bring up the Quick Settings menu. Swipe down further to bring up the Weather and Calendar apps.
6. Anytime to go back to the previous menu, swipe right or press the Home button to go to the Home Screen.
7. While at the Home Screen, swipe up to bring up the Quick Stats menu.
8. While at the Home Screen, swipe left or press the Menu button to bring up the Menu.
9. While at the Home Screen, swipe right to bring up the phonebook.
Note: Your phone needs to be connected to the watch.

Mobile Application:


ActiFit Track can be used with a mobile application available for iOS and Android.

[iOS App store link](#) - "HitFit" | [Google Play Store link](#) - "HitFit"

Connecting to the Application:

1. Turn on the Bluetooth on your mobile device.
2. Open the 'HitFit' application on your mobile device.
 - a) If you are a new member, you will need to register a new account. Be sure to enter your personal information accurately in the given prompts.
 - b) If you are an existing member, you can just input your login email address and password.

3. After logging in click on the "Me" icon and select "Add device".
4. The application will list your smartphone. Please click the "binding" option to search for the device. Once it shows in the list, please click the "binding" option. The application will ask for confirmation, please click on the "pair" option.



iPhone Pairing:

- Follow the above procedure.
- After binding is successful, open the Bluetooth option on iPhone and search for "AFTrack" and pair with it.
- This allows the watch and phone to sync.

Functions:

Phonebook: Your phonebook can be accessed and calls can be received and rejected.

Message: Smartphone messages will sync automatically with watch once connected successfully.

Note: iPhone does not support message synchronization.

Call Logs: You can check your phone call records after you pair the watch with your phone via Bluetooth.

Heart Rate: Wear the watch, go to heart rate tab to monitor your heart rate. It will monitor when the sensor lights up. It takes around 30s to measure the heart rate.

Notification: After pairing with Bluetooth notifications will be sent to the watch.

Settings: Various setting can be changed here including the BT settings

Siri: Once connected to an iPhone Siri can be used from the watch.

Alarm: Set alarm(s) for your various activities with this function.

Target setting: Here your daily targets for steps, distances, calories and exercise time can be set.

Sleep Monitor: The watch will automatically monitor your sleep quality during 22:00-8:00. You can check sleep history by swiping up on the sleep screen. It also syncs sleep data to the app.

Music: Adjust the volume and playback functions of your favorite music app with this menu.

Alt- and Barometer: The Altimeter will automatically update if GPS is on and have been successfully connected to the satellites.



Remote Camera: ActiFit Track can be used to remotely capture pictures from your phone. Open the camera application on your phone, then select the Camera option on ActiFit Track. Click the “Capture” button to take a photo.

Calculator: The ActiFit track has a calculator function for when you need some quick equations calculated.

Stopwatch: You can record your lap times with the stopwatch and see your history by sliding the screen from right to left

Volume adjust: Change the volume level of your device in this option.

Brightness adjust: Change the brightness level of your device’s screen in this option.

Calendar: View the calendar and different months by sliding left and right.

Gesture Control: Change the settings for the gesture control to enable gestures when moving your wrist.

Weather: After connecting to the “HitFit” app the watch will show the local weather.

Sports: ActiFit Track will monitor your vitals depending on the sport you have selected. Select the Sports function and choose from the various options such as Running, Hiking, Biking, Basketball, Table Tennis, Football.


Location: Ensure the GPS function is enabled in the settings menu before accessing this function.

Your location can be displayed on the watch by using the GPS system. Select the location function and wait about 3min for the watch to connect to the GPS network.

Please Note: That GPS system only works when the watch can see the satellite. Performance with buildings and structures may vary.

HitFit Application:


Home Screen: On the home screen of the application all your daily figures can be tracked. Select the weekly exercise to see all the activities of your week.



Profile Page:

On the profile page you can see your user account and Calories burnt while exercising.

Additionally the device’s settings can be viewed and changed on this page.



FAQ

Q) My device’s location isn’t showing ?

A) Ensure the GPS location function is switched on in the settings menu. Make sure there is no obstructions to like buildings or bridges that can prevent the signal from reaching the satellite.

Q) How do I know if the device is fully charged.

A) There is LED’s on the charging dock that indicate the charge status.

Q) How often do I need to sync my data with the phone?

A) Once the “HitFit” App is opened and the device is connected via Bluetooth the sync will automatically update every time.

Q) How can I save my data?

A) Set up an account in the “HitFit” app and log in. Your data will be saved in the cloud and can be restored later.

Maintenance

1. Retain these instructions for future use.
2. Clean the product with a damp cloth and mild soap.
3. Do not expose this product to rain or moisture.
4. Be careful not to turn or twist the cables used in this product too much as it can lead to malfunction and failure.
5. This product is not designed to be submerged in water and will malfunction if this occurs.
6. This product has no user serviceable items inside. Do not open this product as the user risk injury and would void the warranty.
7. Keep unit away from strong magnetic fields to avoid interference with the product.



LIMITED WARRANTY

Merlin Products are covered by a limited one-year warranty policy. If the product suffers from a manufacturing defect, the customer will receive a replacement if claimed within 15 days of the purchase date. Otherwise, the product will be inspected for possible repair options. The product will either be repaired and returned free of charge, or replaced. All repair services past the one-year warranty period will be charged for any repairs that need to be made.

If the client is located outside the UAE, or is otherwise unable to personally deliver the defective product to our service center or retail outlets, he/she may send it via post at his/her own cost. The repaired/replaced product will then be returned to the client via courier mail at Merlin's cost, as long as the warranty period is still active.

Important: This limited warranty DOES NOT COVER normal wear and tear, accidents, damage during transit, misuse, abuse or neglect. Attempting to disassemble the unit will render the warranty null and void.

REGISTER
NOW

We hope you enjoy the quality of Merlin Digital product.

Please take out a few minutes to register your product at merlin-digital.com/register to avail:


- Special discounts and promotions on other Merlin products
- Exclusive information on new products and innovations
- Reminders about product firmware downloads, updates and upgrades
- Competitions and exciting giveaways

To learn more about Merlin products visit our site at: www-merlin-digital.com or like our Facebook page on facebook.com/merlin.digital.gadgets

For enquiries and information call our toll free number 800-MERLIN (Sat-Thu, 9 am - 6 pm)

Contact our support staff for troubleshooting and any other enquiries relating to your Merlin product by sending an email at support@merlin-digital.com and your issue will be resolved within 48 hours.

REGISTER
for exclusive
product releases
and future
prize drawings!



For a complete list of our worldwide locations,
visit <http://merlin-digital.com/contacts>