



NeoPhab

All-in-One Phablet with Anti-Radiation Earphones



Thank you for purchasing this Merlin Product. Please read the instruction manual carefully before using the product.

The documentation provided will allow you to fully enjoy all the features this unit has to offer.

Please save this manual for future reference.

Instructions

SIM Card, TF Card, and Battery Installation

- Carefully remove the back cover, starting from the lower left corner of the phablet.
- Insert your preferred SIM card in the appropriate slot.
- Slot A accepts a standard SIM card. Slot B accepts a mini SIM card. The bottom slot accepts a microSD card.
- Once you insert your SIM and/or microSD cards, install the battery in the correct direction and place the back cover.

General Operation

- Press and hold the power button to turn the device on.
- The phablet has three touch-sensitive buttons in the front.
- Touch the Menu (Square) button to pop up in-app menu. On the home screen, touch the menu button to bring up the quick settings menu (such as Wallpaper, Ringtone, etc).
- To go back from any menu or app, touch the Back (Triangle) button.
- Touch the Home (Circle) button to go to the Home Menu. Touch and hold this button to bring up the 'recently used apps' screen. You can clear all running apps or go to a specific one.
- The phablet doesn't have an app drawer. All your installed apps will be placed on the Home Screen in panes. Swipe left or right to navigate through your apps.
- To uninstall an app, press and hold the app icon and drag it to the 'Uninstall' icon that appears at the top.
- The phablet is powered by Android 5.1 Lollipop. You can download apps as needed from Google Play.
- To charge the device, use the included DC adapter and cable and connect it to the charging port at the top of the device.

Maintenance

- Do not expose the device to extreme temperatures, moisture, or dust.
- Do not drop the device or place heavy objects on it.
- When the device is being formatted or a file is being uploaded or downloaded, please do not disconnect the device. This may cause an application error.
- Do not disassemble the product or use alcohol, thinner, or benzene to clean it.
- Please do not use the device while driving or walking on busy roads.
- The device is not waterproof, so keep it away from water and other liquids.

FAQ

- Q) The device does not start?
A) Check battery power and try charging it.
- Q) The device shuts down after powering up?
A) The device doesn't have enough charge. Please charge.
- Q) No sound can be heard in the earphones?
A) Please check whether the volume is set to zero or if the music file is damaged. Try playing some other file to see if the files are damaged.
- Q) I'm unable to copy files or play music?
A) Please check if your laptop/desktop and device are properly connected and that the USB cables are properly inserted. Check if there's enough storage space left on the device.

LIMITED WARRANTY

Merlin Products are covered by a limited one-year warranty policy. If the product suffers from a manufacturing defect, the customer will receive a replacement if claimed within 15 days of the purchase date. Otherwise, the product will be inspected for possible repair options. The product will either be repaired and returned free of charge, or replaced. All repair services past the one-year warranty period will be charged for any repairs that need to be made.

If the client is located outside the UAE, or is otherwise unable to personally deliver the defective product to our service center or retail outlets, he/she may send it via post at his/her own cost. The repaired/replaced product will then be returned to the client via courier mail at Merlin's cost, as long as the warranty period is still active.

Important: This limited warranty DOES NOT COVER normal wear and tear, accidents, damage during transit, misuse, abuse or neglect. Attempting to disassemble the unit will render the warranty null and void.

REGISTER NOW


We hope you enjoy the quality of Merlin Digital product. Please take out a few minutes to register your product at merlin-digital.com/register to avail:

- Special discounts and promotions on other Merlin products
- Exclusive information on new products and innovations
- Reminders about product firmware downloads, updates and upgrades
- Competitions and exciting giveaways

To learn more about Merlin products visit our site at: www-merlin-digital.com or like our Facebook page on facebook.com/merlin.digital.gadgets
For enquiries and information call our toll free number **800-MERLIN** (Sat-Thu, 9 am - 6 pm)

Contact our support staff for troubleshooting and any other enquiries relating to your Merlin product by sending an email at support@merlin-digital.com and your issue will be resolved within 48 hours.

REGISTER
for exclusive product releases and future prize drawings!



For a complete list of our worldwide locations, visit <http://merlin-digital.com/contacts>