Pocket Projector Wi-Fi

Smart way to engage with your media… wirelessly!

Thank you for purchasing this Merlin Product. Please read the instruction manual carefully before using the product.

The documentation provided will allow you to fully enjoy all the features this unit has to offer.

Please save this manual for future reference.

Instructions

1) Press and hold the 'Power' button for 2 seconds to switch the projector on. Press the 'Power' button once to check battery status.
2) Use the included micro HDMI cable to connect an HDMI device (such as a smartphone) to the projector.
3) To connect via AirPlay, search for projector access point (AP) "MP-328-XXXXXX" in your Apple device's Settings < WLAN menu. Connect to projector AP using password "12345678". Select the projector in AirPlay options and enable "Mirroring".
4) To connect via Miracast, search and connect to projector AP in your phone's wireless display settings.
5) If your smartphone is DLNA-enabled, you can access your phone's media files after connecting to projector AP. You can also install a DLNA streaming app to play your media files via the projector.
NOTE: To switch between Miracast and DLNA modes, press the "M/D" switch button located next to the volume keys on the projector.
6) To connect to the projector via a router, connect to projector AP and go to 192.168.49.1 from your device's browser. Click on the Wi-Fi icon and then 'Scan'. Search and connect to your router AP.

Maintenance

1) When charging the projector, use only a dedicated USB cable or one that can handle current higher than 2.5A.
2) Please use the projector with the included holder. Don't put it on any surface directly when in use.
3) Do not place the projector on shaky surfaces.

4) Do not expose the projector to extreme temperatures or humidity.

FAQ

Q) The projector won't turn on.
A) Ensure that the projector is charged. If not, connect it to the included power adaptor using the provided charging cable.

Q) The projector display is blank.
A) Ensure that the micro-USB cable is fully connected to the power source. Ensure that the HDMI cable is securely connected to the projector and your device.

Q) The projector won't mirror my device via HDMI.
A) Ensure that your device is MHL-enabled.

Q) I can't hear anything from the projector's speaker.
A) Check whether the projector's volume has been set at zero.

Q) I cannot find projector AP in DLNA mode.
A) Ensure that there's a wireless connection (either direct or via a router) between the projector and your device.

Q) Video playback is not smooth in DLNA/Miracast mode.
A) Shorten the distance between your device and the projector. If you're trying to play a large file, let it buffer first.

LIMITED WARRANTY

Merlin Products are covered by a limited one-year warranty policy. If the product suffers from a manufacturing defect, the customer will receive a replacement if claimed within 15 days of the purchase date. Otherwise, the product will be inspected for possible repair options. The product will either be repaired and returned free of charge, or replaced. All repair services past the one-year warranty period will be charged for any repairs that need to be made.

If the client is located outside the UAE, or is otherwise unable to personally deliver the defective product to our service center or retail outlets, he/she may send it via post at his/her own cost. The repaired/replaced product will then be returned to the client via courier mail at Merlin's cost, as long as the warranty period is still active.

Important: This limited warranty DOES NOT COVER normal wear and tear, accidents, damage during transit, misuse, abuse or neglect. Attempting to disassemble the unit will render the warranty null and void.

SERVICE CENTER MAP

For a complete list of our worldwide locations, visit **http://merlin-digital.com/contacts**